

Wiring Harness UL File E144220

The hot wire (usually black or red) needs to be connected to the unmarked smooth wire that leads to the center contact on the socket. The neutral wire (usually white) needs to be connected to the ribbed wire that leads to the screw shell of the socket. The grounding wire (tinned wire) needs to be connected to your ground (bare wire) or to the grounded metal ceiling box. We suggest hiring an electrician for installation.

UL File E144220, Wiring Harness

